

GR-2D


Downflow Regenerate Control Valve

Installation, Use and Maintenance
(GR2-2D\GR4-2D\GR10-2D)



GR-2D-E

Scan Qr code for the latest




GR-2D valve shift animation



GR-2D Install animation




I .The Controller



Pic1: GR-2D Controller interface

(1) Panel indicator and button

1、 Station Indicator

- : Backwash+Refill
- : Brine in →Rinse(when air check)→Wash(Twinkle);
- : Service(Softening)

2、 Control signal light

Light 

lighting, The LED digital display is the clock.

Flashing, It means there is a long time power off (more than 10 days).

That need to set the current clock



Light 



Lighting, means *lock state*, the buttons are locked. Any button is pressed will not work.

Goes out, *Unlock* state,if there is no operation on button in 2 minutes, the

buttons will be automatic locked.





Light






Lighting, indicate under *inquiry* state. The parameters menus can be inquired by   up and down.

Flashing, indicate under *setting* state. The parameters can be changed by   plus and minus



3、Button.


Button

If the button  were pressed under *unlock state*,  indicator lighting, enter into *inquire state*, to inquire parameter menus (follow table) up and down by   button.


Press  under *inquire state*,  flashing, enter to *setting state*, the parameter can be modified by   to plus & minus to modify the value of the blinking digit, press again to switch another blinking digit, finally press  to confirm the modification and return to the *inquire* state.

Button




locking  state, push  6 times, the valve enter into **B.Wash** (Forced backwash)

Press  under *unlock state*, the current valve station will be shift into next (**Manual shift**).

Press  under *inquire state*, return back to *unlock state*.

Press  under *setting state*, return back to *inquire state* and the parameter modified will be not saved.












Button &

Unlock : hold down at the same time button   for around 2 seconds,  light will go out and enter into *unlock state*.



Inquire parameters menus up and down under *inquire state*.

Plus1 and minus1:for digit of each parameter under *setting state*.

(2) Parameters menus


Function	Digital window	Indicator light of LED and instruction
Start up display	L507	S: Time model, L: Meter model 5 means the fifth generation products, 03 means that the current program version
	5507	
clock	12:00	clock, the factory set for random
Unlock state, press “  ” to <i>inquire state</i> , display in turn		
Time model	07.00	 means RUN station. D is unit. Left of “.” is day. Right of “.” is hour, If the unit is M ,Left of “.” is hour. Right of “.” is minute,
	2-06	 B.wash+Refill time, unit is minute (M) ,
	3-36	 Brine→ Rinse time,unit is minute (M)
	4-05	 (Twinkle) Wash time, unit is minute (M)
Meter model	0055	 RUN volume. unit display is M³
	0050	 B.wash+Refill volume. unit is M³
	0.125	 Brine→ Rinse volume,unit is M³
	0.100	 (Twinkle) Wash volume. unit is M³
Output control mode	b-01	Relay output mode include: 00, 01, 02, 03, 04, 05, 06. See section Relay output mode for details.
Delay Regen	99:00	Delay Regeneration,"--:--" lighting; If set left as "99"(default), means cancel the function.
Regen times	L-01	L is setting code. 01 means from  to  once per cycle
Unit D/M of Time model	H-01	00: "-- : --"the unit ahead of “.” is hour , the unit behind of “.” is minutes M 01: "-- : --"the unit ahead of “.” is day D , the unit behind of “.” is hour

Note











1. Under **inquire** state or setting state, if there is no button operation in 30 seconds.,The state will automatically exit.
- 2.During normal operation, the data window will display: station parameters (decreasing state), clock, water inflow flow rate, and corresponding signal indication, station indication, unit indication every 10 seconds
3. Display ,means the valve is shifting to next station.the motor is rotating.
4. Display clock flashing, such as , that means power off time is too long, remind the user to check current time.
5. " E1" display means the system out of order.



(3)、Output control

1、Interlock line connection as below





Explanation:

- A. Any valve at 、 position, the valve can send lock signal.
- B. Any valve from  to 、 position, the program will read locking signal from interlock line. If there are locking signals (that means there are other valves is in 、, the valve will continue service in ,Until other valves finish in 、 (locking signal

disappear), this valve shift to ,  .

C. S1 and S2 is same signal on PCB board. There is no sequence relationship.

3、 Delay regeneration explain :

Under delay regeneration function, when the digital of  station decrease to "0", the equipment will continue in "" until the actual time come to the time of "0-23" clock set in advance.

4. Relay output mode (b-0X)

A. The contact capacity of the relay is 5A/250V.



B. Relay output port:


NO= Normal open port, **NC**=Normal Close port ,**COM** =Common port

C.When connecting the output of the relay, the AC220V power supply input end shall be connected with the leakage circuit breaker.


Different mode, the relay output **NO** and **COM** Connected for "C", disconnect for "x"

Station	B.wash+ Refill	Brine→ Rinse	Wash	Soft	Shifting
Symbol			 Twinkle	RUN	
b=00	C	C	C	C	x
b=01	C	C	C	x	x
b=02	x	x	x	C	x
b=03	C	C	C	x	x
b=04	C	C	C	x	x
b=05	x	x	x	CX	x
b=06	C	x	x	x	x
b=07	C	C	C	x	C
b=08	x	x	x	x	C

Mode	Applications
b=00	Inflow water solenoid valve mode: Pressure relief when valve shifting. water Lever switch, feed pump combine control PIC3
b=01	Booster pump mode: this function is used for filter valve, control backwash pump start-up.
b=02	Out of the water pump start-up mode: For subsequent reverse osmosis high pressure pump startup.
b=03	Tow valve one RUN & one standby inflow water solenoid valve mode: Interlock wire connected. When one valve completes  and  and switches to Run station, judge that if another valve is also Run station, the valve close its own inlet solenoid valve and wait for backup. As shown in PIC 4.
b=04	Tow valve RUN simultaneously Backwash respectively: this mode for filter valve use.
b=05	CX(Mode2 additional conditions) : When the inlet flow meter check the water flow signal in RUN station.the Relay is Connected.
b=06	Backwash booster and compressed air mode
b=07	Only in service, "NO" is open
b=08	Only in the valve shifting, "NO" is closed




Pic3: Mode(b=00): Solenoid valve liquid level switch and feed pump.



Pic4: Mode(b=03): Tow valve one RUN & one standby inflow water solenoid valve mode:

II、Flow Process



Pic5: GR-2D Downflow regenerate flow process

III、 Configuration and Installation

1, If the raw water contains mechanical impurities of gel or powder, it is necessary to install sand filter, cloth bag or disc type functional filter, factory valve inlet filter can only ensure the occasional large particles into the valve body.

2. The volume of the salt tank is not less than the volume of the exchange tank.


3 .The drainage pipe outlet is close to the ground level, too high or too low will affect the brine absorption of equipment.

4, Water static pressure is 0.1MPa ~0.6 MPa

5, water temperature is 0°C ~ 50°C


6, the equipment is installed in the room, the humidity should not be too high, there should be no corrosive chemical gas around, to avoid strong electromagnetic interference to affect the power supply of the control valve.

7,Floor drain or trench drainage shall be set around the equipment to avoid accidental water leakage causing the floor and other indoor items to be flooded.





Pic6: GR-2D configuration and install



GR-2D Downflow Regenerate valve




GR2-2



GR4-2
GR4-2E







GR10-2



Pic7: valve geometric parameter

IV Recommended parameter setting

Station	describe	Formula
	Service	$[\text{resin filling volume (L)} \times 90\%] \div \text{Raw water hardness (mmol/L). unit is m}^3$
	B.wash+Refill	Resin filling volume (L) x 250%(200%+50%)**
	Brine → Rinse	Resin filling volume (L) x 250%(50%+200%)*
 Twinkle	Wash	Resin filling volume (L) x 100%

1 *The setting water refers to the process of jet injection quantity sum, including Brine Absorption 50% and Rinse 200%.

2. **50% is the salt tank refill water and 200% is the B.wash water. This ratio is based on the valve body channel design and test. (50% means 1 liter of pure brine regenerate 2 liters of resin).

3, Water hardness unit is mmol/L


4, Resin work exchange capacity calculating is 1000 mol/m³;


5, Design and calculation of brine concentration is 16%(Dry salt tank dilution concentration) ;


6、1Liter brine(16%)Molar value= $1000g \times 16\% / 58.8g(\text{NaCL}) \times 1.4(\text{Specific consumption}) \approx 160/80=2\text{mol}$

V Steps for initial water supply


1.Make sure that the external pipeline and sealing are strong and the brine pipeline is connected in good condition, and turn on the power.

2.Forced backwash,(press ""6 times lock state),cleaning resin and refill water to salt tank,observe the lever of water in salt tank.

3.To "" station, observe sucking brine and the proportion of brine 50% and rinse 200%,observe drain or taste drainage water.


4.To "Tinkle" Wash station, check the drainage water and sure it clean in the end of the station.

VI. The disassembly of the brine valve and injector




1. End cover; 2. Jet nozzle; 3. Brine valve ; 4. Brine valve core; 5. Pin; 6. fork; 7. Spring; 8, leverage

Pic8.The disassembly of the brine valve and injector




Pic9:Brine valve explode drawing




Pic10: Removal and connection of front shell of the controller


VII. Curve of Flow and Pressure for the Valve



Pic11: GR2-2D Flow pressure curve




Pic12: GR4-2D Flow pressure curve



Pic13: GR10-2D Flow pressure curve

VIII、 Regular failure and failure elimination

Produced water is not qualified

Phenomena/reasons	Solution
No salt particle in the brine tank	Add salt to the brine tank
No enough absorption of salt water	Increase refilling water amount of  setting value
Flow rate is too large, running velocity is too high	Reduce the pressure difference between the inflow and outflow

Brine water leaking out to the water outlet

Phenomena/reasons	Solution
Insufficient amount of washing	Increase wash value to extended wash time
No enough resin and too much space at the top of the swap tank	Add more resin or other to reduce the space

The inlet pressure of the equipment increases and the water output decreases

Phenomena/reasons	Solution
Resin's being polluted by the suspended matter	Forced backwash or Unload the valve and wash the resin both inside and outside the tank.
Strainer is blocked by broken resin	Unload the Strainer and clean it.
Out pipes system have closure phenomenon	Check and eliminate the problem


The salt tank overflowed

Phenomena/reasons	Solutions
 Station setting is too large or the salt tank is too small	Reduce the set value, or increase the salt tank

No brine absorption

Phenomena	Reasons and Solution
Drainage pipe have water out,but no brine absorption	Water distributor inside the exchange tank is blocked, resin is contaminated, or there is interception in the drainage pipe system,
No water out from drain pipe,also no brine absorption.	Mainly is the jet nozzle blocked, (pic:9).

IX. GR-2 valve explode drawing (GR4-2 example)



Pic14: GR-2 valve explode drawing (GR4-2 example)